


Quick **Setup** Guide

Outdoor Security Camera




To view this guide in other languages (e.g. Nederlands, Deutsch, Français, Español), and for detailed manuals, tools, etc., please visit foscam.com/downloads

305503000880

Setting Up Your Foscam Security Camera

1 Getting Started


Package Contents



Security Tips

- Please change the camera's password regularly, using a combination of numbers, letters and special characters.
- We recommend that you regularly update your camera with the latest available software and firmware to ensure the best experience with your camera.

2 Physical Description



of the reach of children.

3 Setting Up Your Camera: Connection via the Foscam App (Recommended)

Before You Get Started

Scan the OR code below to download and install the Foscam APP.








To ensure a smoother video experience on your smart phone, it is recommended that your smart phone meet the following specifications:

- iOS: version 11 or higher.
- Android: 5.0 or higher, using a device with a Graphics Processing Unit (GPU).

Note: For the best experience, please update the APP to the latest version!

■ WiFi Connection

1. Please tighten the antenna clockwise and make sure it is in a vertical position.



2. Plug the power adapter into the camera, and please wait for a few seconds until hearing the "Ready for WiFi configuration"



3. Make sure that your smart phone is connected to your WiFi router.




4. Open the foscam APP and please register a Foscam account, or sign in if you have one already.








5. Follow the steps below:












Note: If the adding process fails, please reset your camera and try adding again according to the above method.



4 PC Access Your Camera

■ Foscam VMS

Foscam VMS is a new tool for PCs. It does not require plug-ins and is compatible with Windows & Mac, supporting all Foscam HD cameras and up to 36 cameras at the same time. If you would like to manage multiple cameras, we suggest you install Foscam VMS. You can download the "Foscam VMS " Windows version from **foscam.com/yms**, and can download the "Foscam VMS" Mac version from the APP store:


https://apps.apple.com/cn/app/foscamvms/id1521202507?mt=12

Note: For the best experience, please update Foscam VMS to the latest version!


Add the IP Camera

- 1. Run Foscam VMS, then create a local administrator account
- 2. Tap the "+" icon on the Foscam VMS and follow the setup wizard to add vour camera.

Please visit **foscam.com/downloads** to view the user manual and for additional detailed steps.



5 Hardware Installation



Point the camera at the desired location and use the screws provided to mount it.

Please Note:


Ensure that rain or water will not reach the connector ports at the end of the tailcable. These connectors are not weather-resistant.

6 Important Notice

button.

■ Camera Username & Password

The camera username & password are used to access and manage your camera. Having a strong password can significantly improve the security of your camera. If you have forgotten either of them, please press the "Reset"



Press the "Reset" button and hold it for more than 3~5 seconds

Storage Media

Your camera supports cloud, NVR (Network Video Recorder). and Micro SD card (supports FAT32 and exFAT format) storage formats.





6 Foscam Format **FOSCAM** Choose the SD card → Accept Terms of us 2 Terms of use

How to format Micro SD card, please follow the steps below:


Foscam Format

Format ready

Removable Disk (F:)

Open in new window

Open



Scan the QR code below to download the Open the "FoscamFormat" Tool




foscam.com/downloads/app_software.html



"FoscamFormat" Tool





Safety Tips

General Tools Hardware Sharing ReadyBoost Customize

File system: FAT32


Used space: \$6,304 bytes 96.0 KB

Free space: 125,038,362,624 bytes 116 GB

Capacity: 125,038,460,928 bytes 116 GB

OK Cancel Apply







Prohibit use at

low temperature





Keep dry







7 Product Performance

WLAN frequency range: 2412MHz - 2472MHz and 5725MHz - 5850MHz Maximum transmission power: < 18dBm

Wireless Standard: IEEE802.11b/g/n (2.4GHz) IEEE802.11a/n/ac (5GHz)

Power Supply: DC 12V 1.0A 12W




Keep away from fire



Use the supplied screw pack








reset steps.

camera to set up the wireless connection for the camera. Please make sure your cellphone is connected to that new WiFi.



8 Troubleshooting IP cameras is not powering on



Co.. Ltd

- 2. Please check whether the DC adapter is working or not. If you have another 12V/1A power adapter which is working, please try with another power adapter and see whether it will work.
- 3. If it still won't work, please contact Foscam support.

it will work

How to re-configure the WiFi connection for Foscam cameras after router changed?





Then please open the Foscam app to scan the QR-code of your







CF Certificate statement Website: https://www.foscam.com/company/ce-certificate.html

Exporter and Importer Information Opened to Public: https://www.foscam.com/company/open-information.html







Manufacturer: Shenzhen Foscam Intelligent Technology

Addr: Room 901-902, Building 1B, Shenzhen International Innovation Valley, Xingke 1st Street, Nanshan District, Shenzhen, Guangdong, China, 518055

www.foscam.com

Due to product upgrades and other reasons, this guide may be slow to update, resulting in slight inconsistencies with the official website information. Please take the official website (www.foscam.com) information as the current standard.